CONTACT US
W: www.mokasfx.com
E: info@mokasfx.com

MOKA SFX®
AMAZING BOOSTER FOR STAGE

PRODUCT:POWER DROP

MODEL: MK-PD01

USER MANUAL



VERSION 2.0

1.DISCLAIMER

NOTICES:

1. Please read carefully this manual before using.
2. Only special 250V/10A (110V available) three wire power supply to be used, it should be grounded and don't keep earth line and live line together.
3. Must unplug the power cable when you do not use the machine, clean, install or removeaccessories.
4. Do not use this machine in the rainy or humid environment.
5. It is forbidden to put the machine, power plug or cable in the water or other liquid.
6. The power drop has automatic power-off protection function, when the machine is powered for 3s, it will automatically power off to avoid damage, if need it works again, just disconnect the power supply , and then sending electricity, it will be ready for working now.
7. Make sure all parts are set at positions before using.
8. If power drop damaged, please cut off the power right now, and please do not take apart the machine to avoid the danger.
9. Do not use the damaged machine again, in order to avoid the danger.
10. It is forbidden to beyond the maximum loading (5 Kg)

2.CONGRATULATIONS

As a well-established company in the entertainment industry, MOKA SFX specializes in the manufacturing the special SFX and lighting system. All our products are made under the brand name MOKA SFX ® which by now has acquired a great reputation on account of its quality and reliability. MOKA SFX manages the entire production process in-house,from the design stages and prototyping to production. In short, we cover everything from concert to ready to use product.MOKA SFX®is used by special effects professionals all over the world and our products are distributed through a dealer network with covers more than 80 countries.

Congratulations and enjoy your purchase!

3.PRODUCTS FEATURES

1. Advanced design.
2. Power control mode.
3. Automatic power-off protection function.

4.TECHNICAL PARAMETERS

Item Name	Power Drop
Voltage	AC110V/ 220V, 50Hz/ 60Hz
Power	100 w
Size	31 x 13 x 13 cm
Weight	1.4 kg

Notice: The company reserves the right of product improvement and technical parameters of the renewal right, the product you bought may have improved, but not completely consistent with the specifications, sorry we will not inform specially, please check the product nameplate on the labels!

5.INSTALLATION INSTRUCTION

5.1 Installation Preparation:

1> Open packing, check the parts and document, and read the manual carefully.
2> It is forbidden to beyond the Maximum loading (25 kg).
3> At the first using, please check the machine and parts are completely.
4> Check the power and socket whether suitable for the standard.
5> Check whether any dangers around the machine.

5.2 Installation

1> Fixed the power drop at required position.
2> Plug the suitable power cable.(Please do not turn on the power)

6.INSTALLATION INSTRUCTION

6.1 Operation:

1> Unpack after receiving the new machine.Examine for any damage and missing accessories.If necessary,contact your suplier in time.

2> accessories include, power drop machine 1pc,alnico hook 1pc,power cable 1pc,power output plugs 1pc,use manual1pc.

3> Install the power drop machine in place,hang stage screen in the machine hook,connect power cable.

4> this machine divided into power and DMX512 two control mode,if choose power control please pull out switch in POWER this place, if choose DMX control please pull out switch in DMX this place. DMX is one channels. this machinecan in series more machine work in double harness.

5> screen drop after,the machine hook become downfall orientation,if need to use again,please shall machine hook replacement by manual

6.2 Disassembly:

1> At first, turn off the power.

2> Revert the hook

3> Take apart the hook.

7.TROUBLE SHOOTING

No.	Problem	Reason	Solve
1	Curtain cannot be		
put down	Power is not turned on.	Turn on the power.	
		Curtain hanging position is wrong.	Hang the curtain on thehook's bottom.
		Weight is over 25 kg.	Reduce the weight.

8.AFTER-SALE SERVICE

The warranty time is one year from the date of purchase, you can get help and solve way through our technical support at any time. We could offer free parts necessary to repair products. One of the following conditions not covered under warranty:

• Because the consume ruse,maintenance,transportation, damage caused by improper storage;

• Non designated personnel to repair the damage caused by the disassembly of products;

• Because of damage caused by force majeure Abnormal voltage, such as fire,earthquake,tsunami, debris flow;

• More than the warranty period.

* if found quality problems please contact sales center or after sale service, do not disassemble, due to quality problems caused by selfdisassembly or accident,the company will not bear any responsibility.

MOKA SFX®

W: www.mokasfx.com

E: info@mokasfx.com